

- HA-8P-X4G3-FF-X16G3
Host adapter

XIMEA Accessories ●
Technical Manual ●
Version v260128 ●

Introductions

About this manual

Dear customer,

Thank you for purchasing a product from XIMEA.

We hope that this manual can answer your questions, but should you have any further queries or if you wish to claim a service or warranty case, please contact your local dealer or refer to XIMEA Support on our website: www.ximea.com/support

The purpose of this document is to provide a description of XIMEA Accessories and to describe the correct way to install related software, drivers and run it successfully. Please read this manual thoroughly before operating your new XIMEA Accessories for the first time. Please follow all instructions and observe the warnings.

This document is subject to change without notice.

About XIMEA

XIMEA is one of the worldwide leaders for innovative camera solutions with a 30-year history of research, development and production of digital image acquisition systems. Based in Slovakia, Germany and the US, with a global distributor network, XIMEA offers their cameras worldwide. In close collaboration with customers XIMEA has developed a broad spectrum of technologies and cutting-edge, highly competitive products.

XIMEA's camera centric technology portfolio comprises a broad spectrum of digital technologies, from data interfaces such as USB 2.0, USB 3.1 and PCIe to cooled digital cameras with CCD, CMOS and sCMOS sensors, as well as X-ray cameras.

XIMEA has three divisions – generic machine vision and integrated vision systems, scientific imaging and OEM/custom.

Our broad portfolio of cameras includes thermally stabilized astronomy and x-ray cameras, as well as specialty cameras for medical applications, research, surveillance and defense.

Contact XIMEA

XIMEA is a worldwide operating company

Headquarters, Sales worldwide

XIMEA GmbH
Am Mittelhafen 16
48155 Münster
Germany

Tel: +49 (251) 202 408-0
Fax: +49 (251) 202 408-99

Web www.ximea.com
General inquiries info@ximea.com
Sales sales@ximea.com
Support [XIMEA Support](#)

Sales America

XIMEA Corp.
12600 W Colfax Ave., Suite A-130
Lakewood, CO 80215
USA

Tel: +1 (303) 389-9838
Fax: +1 (303) 202-6350

R&D, Production

XIMEA s.r.o.
Lesná 52
900 33 Marianka
Slovakia

Tel: +421 (2) 205 104 26
Fax: +421 (2) 205 104 27

Contents

About this manual	2
About XIMEA	2
Contact XIMEA	2
1 General description	4
2 Dimensional drawings	5
3 Configuration	6
3.1 DIP switches	6
3.1.1 GPI GPO configuration DIP switches	6
3.1.2 PCIe configuration DIP switches	6
4 Connectors	8
4.1 Location of connectors	8
4.2 Data interfaces	9
4.2.1 FireFly connectors	9
4.2.2 Power connector	10
4.2.3 CAM power selection jumper header (3-pin)	10
4.3 GPIO connectors	11
4.3.1 External GPI connector	11
5 Usages	12
5.1 Buttons	12
5.1.1 Trigger button	12
5.1.2 PCIe reset button	12
6 Quickstart guide	13
6.1 Hardware setup	13
6.1.1 Essential components	13
6.1.2 Connecting the components	13
List of figures	14
List of tables	15

1 General description




Figure 1: Isometric view of host adapter HA-8P-X4G3-FF-X16G3

- Firefly dual host adapter with 8x Firefly Connectors
- 8x Gen.3 PCIe x4 Firefly downstream ports - 32 Gbits bandwidth each
- Firefly cables provide length options of up to 3 m
- Upstream port PCIe Gen3 x16 - output bandwidth of 128 Gbits

PCIe Gen3 camera accessory host adapter for fiber optics and copper cables. Host adapter has 8 ports for PCIe Gen.3 x4 Firefly cables. Supports Gen 1, Gen 2 and Gen 3 (8.0 GT/s) data rates. Ideal for synchronization of 8 cameras with Firefly connectors from xiX family see: [xiX cameras with PCIe interface](#).

2 Dimensional drawings




Figure 2: Dimensions of host adapter

Width [W]	Height [H]	Depth [D]	Mass [M]	Cooling options
168 mm	121.5 mm	29.8 mm	213 g ¹	For heatsink options please contact sales

¹Weight and maximal width / depth are measured with attached heatsink

Table 1: Parameters and mass

3 Configuration

3.1 DIP switches

3.1.1 GPI GPO configuration DIP switches

The host adapter includes an 8-position DIP switch labeled GPI, which is used for configuring external triggering the cameras.




Figure 3: GPI / GPO DIP switches

To enable external triggering for one or more cameras, follow these steps:

For each camera you want to trigger externally, set the corresponding switch on the GPI DIP switch block to the ON position. Set the central DIP switch to the EXT (external) position. This enables external triggering functionality. Provide an appropriate external voltage in the range of 3.3 V to 24 V to the 3-pin connector located directly beneath the central DIP switch (see section [External GPI connector](#) for further information about connector).

3.1.2 PCIe configuration DIP switches

The numbering of the camera ports correspond to the number of the respective GPI and GPO dip switches.

The DIP switches have annotation on their body. The description of DIP switches (GPI, GPO) is written directly on the PCB top layer.




Figure 4: DIP switches location

DIP switch [1] position	DIP switch [0] position	PCle blade lines	FireFly 1 lines	FireFly 2 lines	FireFly 3 lines	FireFly 4 lines	PCle port configuration
0	1	x16	(A+B)=x8	(A+B)=x8	(C+D)=x8	(C+D)=x8	port A / B - Port 1 ¹ port C / D - Port 3 ¹
Z	0	x16	(A+B)=x8	(A+B)=x8	x4	x4	port A / B - Port 1 ¹ port C - Port 3 port D - Port 4
Z	Z	x16	x4	x4	x4	x4	port A - Port 1 port B - Port 2 port C - Port 3 port D - Port 4

¹FireFly ports (x+y) together work as a single X8G3 PCIe port

Table 2: DIP switch configuration, FireFly port 1-4

DIP switch [1] position	DIP switch [0] position	PCle blade lines	FireFly 5 lines	FireFly 6 lines	FireFly 7 lines	FireFly 8 lines	PCle port configuration
0	1	x16	(E+F)=x8	(E+F)=x8	(G+H)=x8	(G+H)=x8	port E / F - Port 5 ¹ port G / H - Port 7 ¹
Z	0	x16	(E+F)=x8	(E+F)=x8	x4	x4	port E / F - Port 5 ¹ port G - Port 7 port H - Port 8
Z	Z	x16	x4	x4	x4	x4	port E - Port 5 port F - Port 6 port G - Port 7 port H - Port 8

¹FireFly ports (x+y) together work as a single X8G3 PCIe port

Table 3: DIP switch configuration, FireFly port 5-8

4 Connectors

4.1 Location of connectors




Figure 5: Location of connectors

Connector	Description
FF1 - FF8	PCIe FireFly downstream connectors
IO1 - IO8	3 Positions Header, Shrouded Connector (1.50 mm) Through Hole Tin-Lead
EX_GPI	External GPI connector 3 Positions Header, Shrouded Connector (1.50 mm) Through Hole Tin-Lead
PCIe x16	PCIe x16 PCB Edge connector
PWR_SEL	Camera power selection jumper CONN HEADER SNGL STR 3POS
PWR	Power Connector Header Through Hole, 2 position (2.50 mm)

Table 4: Description of connectors

4.2 Data interfaces

4.2.1 FireFly connectors




Figure 6: Firefly connectors pinout

Pin	Name	Type	Pin	Name	Type
A1	GND	Signal and power ground	B1	GND	Signal and power ground
A2	PCle_PETN_2	PCle TX differential pair 2	B2	PCle_PETN_3	PCle TX differential pair 3
A3	PCle_PETP_2	PCle TX differential pair 2	B3	PCle_PETP_3	PCle TX differential pair 3
A4	GND	Signal	B4	GND	Signal and power ground
A5	PCle_PETN_1	PCle TX differential pair 1	B5	PCle_PETN_0	PCle TX differential pair 0
A6	PCle_PETP_1	PCle TX differential pair 1	B6	PCle_PETP_0	PCle TX differential pair 0
A7	GND	Signal and power ground	B7	GND	Signal and power ground
A8	IN1	Optically isolated Digital Input (IN)	B8	OUT1	Optically isolated Digital Output (OUT)
A9	IN1_GND	Ground for opto-isolated Input 1	B9	OUT1_GND	Ground for opto-isolated Output 1
A10	GND	Signal and power ground	B10	GND	Signal and power ground
A11	PCle_RST0_N_IN	PCle reset	B11	PWR	Power input
A12	NC	None	B12	PWR	Power input
A13	GND	Signal and power ground	B13	GND	Signal and power ground
A14	PCle_PERP_2	PCle RX differential pair 2	B14	PCle_PERN_3	PCle RX differential pair 3
A15	PCle_PERN_2	PCle RX differential pair 2	B15	PCle_PERP_3	PCle RX differential pair 3
A16	GND	Signal and power ground	B16	GND	Signal and power ground
A17	PCle_PERP_1	PCle RX differential pair 1	B17	PCle_PERN_0	PCle RX differential pair 0
A18	PCle_PERN_1	PCle RX differential pair 1	B18	PCle_PERP_0	PCle RX differential pair 0
A19	GND	Signal and power ground	B19	GND	Signal and power ground

Table 5: FireFly connector (UEC5) pin assignment

Pin	Name	Type
1	VCC_TX	Power output
2	GND	Ground
3	NC	None
4	NC	None
5	PCle_RST0_N_IN	PCle reset
6	NC	None
7	NC	None
8	NC	None
9	OUT1	Optically isolated Digital Output (OUT)
10	VCC_RX	Power output

Table 6: FireFly connector (UEC8) pin assignment

4.2.2 Power connector




Figure 7: Power connector pinout

Pin	Name	Type
1	GND	Ground
2	PWR	12 to 24 V

Table 7: Power connector (2POS) pin assignment

4.2.3 CAM power selection jumper header (3-pin)




Figure 8: Jumper header (3POS) pinout

Pin	Name	Type
1	12V	12 V power from PCIe blade
2	CAM	Camera power input
3	AUX	External power from AUX/GND pin

Table 8: Jumper header (3POS) pin assignment

Placing the jumper on CAM-12V pins enables camera power from the PCIe blade. Alternatively, placing the jumper on CAM-AUX pins enables camera power from the GND/AUX connector.

4.3 GPIO connectors




Figure 9: IO connectors pinout

Pin	Connector 1	Connector 2	Connector 3	Connector 4	Connector 5	Connector 6	Connector 7	Connector 8
1	ISO_GPI_1	ISO_GPI_2	ISO_GPI_3	ISO_GPI_4	ISO_GPI_5	ISO_GPI_6	ISO_GPI_7	ISO_GPI_8
2	ISO_GND							
3	ISO_GPO_1	ISO_GPO_2	ISO_GPO_3	ISO_GPO_4	ISO_GPO_5	ISO_GPO_6	ISO_GPO_7	ISO_GPO_8

Table 9: GPIO connectors pin assignment

4.3.1 External GPI connector




Figure 10: External GPI trigger connector pinout

Pin	Name	Type
1	EXT_GPI	External GPI (General Purpose Input) signal — used when switch is in EXT mode
2	GND	Ground
3	TRIG_3V3	Trigger signal at 3.3 V logic level

Table 10: External GPI trigger connector pin assignment

5 Usages

5.1 Buttons

5.1.1 Trigger button

This button can be used to generate a trigger pulse on the GPI-Selector output position to test the GPI configuration.




Figure 11: Trigger button

5.1.2 PCIe reset button

Pressing this button will result in reset of the Adapter PCIe bus and all connected cameras.




Figure 12: PCIe reset button

Note: This PCIe reset button is for debugging purposes only.

6 Quickstart guide

6.1 Hardware setup

6.1.1 Essential components

- Host computer with at least a PCIe Gen 3 x8 slot (PCIe x16 Gen 3 recommended for optimal performance)
- HA-8P-X4G3-FF-X16G3 host adapter
- Firefly ECUE copper cable (e.g. CBL-ECUE-X4G3-1M0)

6.1.2 Connecting the components

- Step 1.** Deploy the host adapter to the turned-off PC and ensure the PC is also unplugged from the power source
- Step 2.** Connect the cables to the host adapter
- Step 3.** Connect the necessary cables to the connected device (e.g., the camera)
- Step 4.** Power up the connected device
- Step 5.** Power up the PC

For more information about HA-8P-X4G3-FF-X16G3 please contact: sales@ximea.com.

List of Figures

1	Isometric view of host adapter HA-8P-X4G3-FF-X16G3	4
2	Dimensions of host adapter	5
3	GPI / GPO DIP switches	6
4	DIP switches location	6
5	Location of connectors	8
6	Firefly connectors pinout	9
7	Power connector pinout	10
8	Jumper header (3POS) pinout	10
9	IO connectors pinout	11
10	External GPI trigger connector pinout	11
11	Trigger button	12
12	PCIe reset button	12

List of Tables

- 1 Parameters and mass 5
- 2 DIP switch configuration, FireFly port 1-4 7
- 3 DIP switch configuration, FireFly port 5-8 7
- 4 Description of connectors 8
- 5 FireFly connector (UEC5) pin assignment 9
- 6 FireFly connector (UEC8) pin assignment 10
- 7 Power connector (2POS) pin assignment 10
- 8 Jumper header (3POS) pin assignment 10
- 9 GPIO connectors pin assignment 11
- 10 External GPI trigger connector pin assignment 11



